



Mobile TD/TTC/LTE

PC Tools for TD/TTC/LTE

CPFilterOnAP UserGuide

V1.0

Document Conventions



Note: Provides related information or information of special importance.



Caution

Caution: Indicates potential damage to hardware or software, or loss of data.



Warning: Indicates a risk of personal injury.

Document Status

Doc Status: UE ConSole User Guide

Technical Publication:

For more information, visit our website at: www.asrmicro.com

Disclaimer

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of Asrmicro. ASR retains the right to make changes to this document at any time, without notice. ASR makes no warranty of any kind, expressed or implied, with regard to any information contained in this document, including, but not limited to, the implied warranties of merchantability or fitness for any particular purpose. Further, ASR does not warrant the accuracy or completeness of the information, text, graphics, or other items contained within this document.

ASR products are not designed for use in life-support equipment or applications that would cause a life-threatening situation if any such products failed. Do not use ASR products in these types of equipment or applications.

Copyright © 2020. ASR International Ltd. All rights reserved..

Table of Contents

1	前言.....	4
1.1	CPFILTERONAP 主要功能.....	4
2	使用用法.....	5
2.1	启动 CPDIAGFILTERONAP.....	5
2.2	ADD FILTER.....	5
2.3	GET FILTER.....	6
2.4	DELETE FILTER.....	6
3	APPENDIX.....	7
3.1	REPORT ISSUES.....	7
3.2	UPDATE THIS DOCUMENT.....	7
3.3	REVISION HISTORY.....	7

1 前言

1.1 CPFilterOnAP 主要功能

在AP上对CP log进行Filter, CPFilter保存在文件系统且可以有多个，用文件名区分，Reboot后仍有效。


通过AP DIAG命令来操作CPFilter目前支持：增加、查询、删除。

2

使用用法


2.1 启动 CPDiagFilterOnAP

- 1、在 CATStudio 窗口->Modules->UeFilter。
- 2、UeFilter 窗口，点击”CP Diag Filter ON AP” 按钮，如下图所示：




2.2 Add Filter

向 UE 新增 Filter 文件配置，方法如下图所示：



2.3 Get Filter

1、从 UE 获得 Filter 文件配置，方法如下图所示：



2.4 Delete Filter

1、从 UE 中删除 Filter 文件，方法如下图所示：



3 Appendix

3.1 Report issues

Please visit webs: <http://support.asrmicro.com>.

Or contact ASR FAE/AE

Or please send email to lianghuxu@asrmicro.com with "PC Tools User Doc Issue/Update: ..." title

Or submit an issue at CQ web: <http://sh2-cq01.asrmicro.com/cqweb/login>.

3.2 Update this document

Please send updated document to lianghuxu@asrmicro.com with "PC Tools User Doc Issue/Update: ..." title for merging, and you will receive merged latest version.

3.3 Revision History

Rev	Description	Date
1.00	Initial version	2012-04-11
1.01	Commit to SVN.	2012-04-19