



Mobile TD/TTC/LTE

PC Tools for TD/TTC/LTE

DualSim UserGuide

V1.0

Document Conventions



Note: Provides related information or information of special importance.



Caution

Caution: Indicates potential damage to hardware or software, or loss of data.



Warning: Indicates a risk of personal injury.

Document Status

Doc Status: Communication UserGuide

Technical Publication: v1.0

For more information, visit our website at: www.asrmicro.com

Disclaimer

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of Asrmicro. ASR retains the right to make changes to this document at any time, without notice. ASR makes no warranty of any kind, expressed or implied, with regard to any information contained in this document, including, but not limited to, the implied warranties of merchantability or fitness for any particular purpose. Further, ASR does not warrant the accuracy or completeness of the information, text, graphics, or other items contained within this document.

ASR products are not designed for use in life-support equipment or applications that would cause a life-threatening situation if any such products failed. Do not use ASR products in these types of equipment or applications.

Copyright © 2020. ASR International Ltd. All rights reserved..

Table of Contents

1	USAGE.....	4
1.1	PREREQUISITE KNOWLEDGE.....	4
1.2	MINIVIEWER TASKNAME FILTER.....	4
1.3	LOGVIEWER TASKNAME FILTER.....	6
2	APPENDIX.....	7
2.1	REPORT ISSUES.....	7
2.2	UPDATE THIS DOCUMENT.....	7
2.3	REVISION HISTORY.....	7


1 USAGE

1.1 Prerequisite Knowledge

Catstudio support dual SIM card display. It defines Target Task ID and Source Task ID in configuration files. Catstudio distinguish SIM0 & SIM1 by configuration file.

1、Catstudio default configuration file location as below:

- 1) Exec\Filter Files\ Sim0TaskNameList.txt
- 2) Exec\Filter Files\ Sim1TaskNameList.txt




2、SIM0&SIM1 revelation principle:


- (1) When Source Task ID and Target Task ID all have SIM0, the message only display on SIM0.
- (2) When Source Task ID and Target Task ID all have SIM1, the message only display on SIM1.
- (3) When Source Task ID and Target Task ID all have SIM0&SIM1, the message 该条 only display on “ALL”.
- (4) If Source Task ID and Target Task ID don't have SIM0 and SIM1, the message display on “ALL”.

1.2 MiniViewer TaskName Filter


- (1) MiniViewer menu: Display->TaskName Filter->All



(2) MiniViewer Menu Display->TaskName Filter->SIM0




(3) MiniViewer Menu Display->TaskName Filter->SIM1



1.3 LogViewer TaskName Filter

LogViewer Window Menu: Filter->TaskNameFilter.



2 Appendix

2.1 Report issues

Please visit webs: <http://support.asrmicro.com>.

Or contact ASR FAE/AE

Or please send email to lianghuxu@asrmicro.com with "PC Tools User Doc Issue/Update: ..." title

Or submit an issue at CQ web: <http://sh2-cq01.asrmicro.com/cqweb/login>.

2.2 Update this document

Please send updated document to lianghuxu@asrmicro.com with "PC Tools User Doc Issue/Update: ..." title for merging, and you will receive merged latest version.

2.3 Revision History

Rev	Description	Date
1.00	Initial version	2013-8-28