



Mobile TD/TTC/LTE

PC Tools for TD/TTC/LTE

UELogExporter User Guide

V1.1

Document Conventions



Note: Provides related information or information of special importance.



Caution

Caution: Indicates potential damage to hardware or software, or loss of data.



Warning: Indicates a risk of personal injury.

Document Status

Doc Status: UE LogExporter User Guide

Technical Publication:

For more information, visit our website at: www.asrmicro.com

Disclaimer

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of Asrmicro. ASR retains the right to make changes to this document at any time, without notice. ASR makes no warranty of any kind, expressed or implied, with regard to any information contained in this document, including, but not limited to, the implied warranties of merchantability or fitness for any particular purpose. Further, ASR does not warrant the accuracy or completeness of the information, text, graphics, or other items contained within this document. ASR products are not designed for use in life-support equipment or applications that would cause a life-threatening situation if any such products failed. Do not use ASR products in these types of equipment or applications.

Copyright © 2020. ASR International Ltd. All rights reserved..

Table of Contents

1	前言.....	4
2	使用用法.....	5
2.1	根据 FILELIST 模板，配置用户所需的 FILELIST 文件.....	5
2.2	选择配置完成的 FILELIST 文件.....	5
2.3	选择文件保存的路径.....	6
2.4	开始拷贝文件.....	6
3	APPENDIX.....	7
3.1	REPORT ISSUES.....	7
3.2	UPDATE THIS DOCUMENT.....	8
3.3	REVISION HISTORY.....	8

1 前言

CATStudio UeLogExporter 模块的功能是：通过 ADB，将 UE 上指定的文件拷贝到本机电脑。用户需根据 FileList 模板定义 FileList，通过 FileList 指定需要拷贝的文件，并将文件保存到指定路径。

2 使用用法


2.1 根据 FileList 模板，配置用户所需的 FileList 文件

- 1、指定文件所在的根目录，以‘/’结束；
- 2、在 remote 指定抓取文件的名称。如果想拷贝目录下的所有文件，可以使用*.*。
- 3、如果希望拷贝如下文件: /tmp/MRD_mutex.bin, /tmp/REM_mutex.bin, /NVM/AcStatOption.nvm, /NVM/mdb/*.*。FileList 的配置实例如下图：


```
Folder = /tmp/  
remote = MRD_mutex.bin  
remote = REM_mutex.bin  
  
Folder = /NVM/  
remote = AcStatOption.nvm  
remote = mdb/*.*
```

2.2 选择配置完成的 FileList 文件

- 1、启动 CatStudio , 在 utility 中选择 UeLogExporter;.
- 2、选择 FileList 文件，如下图所示：




- 3、选择 FileList 文件后，如下图所示：




2.3 选择文件保存的路径

1、选择输出的路径，如下图所示：




2、选择输出的路径后，如下图所示：




2.4 开始拷贝文件

1、点击 Start Export 按钮，如下图所示：



2、拷贝完成后，会弹出目标目录，如下图所示：



3、拷贝是否成功的信息会保存在 ULogExporter.log，如下图所示：

```
ULogExporter v1.0.0.1: PullFiles() - begin
/tmp/MRD_mutex.bin:      Fail
/tmp/REM_mutex.bin:      Fail
/NVM/AcStatOption.nvm:   Success
/NVM/mdb/:               Success
```

3 Appendix

3.1 Report issues

Please visit webs: <http://support.asrmicro.com>.

Or contact ASR FAE/AE

Or please send email to lianghuxu@asrmicro.com with "PC Tools User Doc Issue/Update: ..." title

Or submit an issue at CQ web: <http://sh2-cq01.asrmicro.com/cqweb/login>.

3.2 Update this document

Please send updated document to lianghuxu@asrmicro.com with "PC Tools User Doc Issue/Update: ..." title for merging, and you will receive merged latest version.

3.3 Revision History

Rev	Description	Date
1.0	Initial version.	2014/7/25
1.1	Change FileList format.	2014/9/25