



Mobile TD/TTC/LTE

PC Tools for TD/TTC/LTE

UELogExporter User Guide

V1.1

Document Conventions

	Note: Provides related information or information of special importance.
 Caution	Caution: Indicates potential damage to hardware or software, or loss of data.
	Warning: Indicates a risk of personal injury.

Document Status

Doc Status: UE LogExporter User Guide	Technical Publication:
---------------------------------------	------------------------

For more information, visit our website at: www.asrmicro.com

Disclaimer

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of Asrmicro. ASR retains the right to make changes to this document at any time, without notice. ASR makes no warranty of any kind, expressed or implied, with regard to any information contained in this document, including, but not limited to, the implied warranties of merchantability or fitness for any particular purpose. Further, ASR does not warrant the accuracy or completeness of the information, text, graphics, or other items contained within this document.

ASR products are not designed for use in life-support equipment or applications that would cause a life-threatening situation if any such products failed. Do not use ASR products in these types of equipment or applications.

Copyright © 2020. ASR International Ltd. All rights reserved..

Table of Contents

1	PREFACE.....	4
2	USAGE.....	4
2.1	ACCORDING TO THE TEMPLATE, CREATE FILELIST FILE.....	4
2.2	SELECT THE FILELIST FILE.....	5
2.3	SELECT THE OUTPUT FOLDER.....	5
2.4	COPY FILES.....	6
3	APPENDIX.....	7
3.1	REPORT ISSUES.....	7
3.2	UPDATE THIS DOCUMENT.....	7
3.3	REVISION HISTORY.....	7

1

PREFACE

CATStudio UeLogExporter can copy files from UE to PC.

According to the FileList template, user should write FileList file.

User need select the FileList file and output folder.

2

USAGE


2.1 According to the template, create FileList file

- 1、 Folder parameter: the folder path, need end of string '/';
- 2、 Remote parameter: files' name;
- 3、 If user wants to copy these files from UE: /tmp/MRD_mutex.bin, /tmp/REM_mutex.bin, /NVM/AcStatOption.nvm, /NVM/mdb/*.*. The FileList file should be as follows:


```
Folder = /tmp/  
remote = MRD_mutex.bin  
remote = REM_mutex.bin  
  
Folder = /NVM/  
remote = AcStatoption.nvm  
remote = mdb/*.*
```

2.2 Select the FileList file

- 1、Run CatStudio , select UeLogExporter in utility menu;.
- 2、Select the FileList file:




- 3、After selecting the FileList file:




2.3 Select the output folder

- 1、Select the folder path:




2、 After selecting the folder path:




2.4 Copy files

1、 Press Start Export button:



2、 After the operation, Popup the output folder:



3、The operation's result is saved in UELogExporter.log:

```
UELogExporter v1.0.0.1: PullFiles() - begin
/tmp/MRD_mutex.bin:      Fail
/tmp/REM_mutex.bin:      Fail
/NVM/AcStatOption.nvm:   Success
/NVM/mdb/:               Success
```

3 Appendix

3.1 Report issues

Please visit webs: <http://support.asrmicro.com>.

Or contact ASR FAE/AE

Or please send email to lianghuxu@asrmicro.com with "PC Tools User Doc Issue/Update: ..." title

Or submit an issue at CQ web: <http://sh2-cq01.asrmicro.com/cqweb/login>.

3.2 Update this document

Please send updated document to lianghuxu@asrmicro.com with "PC Tools User Doc Issue/Update: ..." title for merging, and you will receive merged latest version.

3.3 Revision History

Rev	Description	Date
1.0	Initial version	2014-7-25
1.1	Change FileList format	2014/9/25