



Mobile TD/TTC/LTE

PC Tools for TD/TTC/LTE

UEFilter UserGuide

V1.0

Document Conventions

	Note: Provides related information or information of special importance.
 Caution	Caution: Indicates potential damage to hardware or software, or loss of data.
	Warning: Indicates a risk of personal injury.

Document Status

Doc Status: UE ConSole User Guide	Technical Publication:
-----------------------------------	------------------------

For more information, visit our website at: www.asrmicro.com

Disclaimer

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of Asrmicro. ASR retains the right to make changes to this document at any time, without notice. ASR makes no warranty of any kind, expressed or implied, with regard to any information contained in this document, including, but not limited to, the implied warranties of merchantability or fitness for any particular purpose. Further, ASR does not warrant the accuracy or completeness of the information, text, graphics, or other items contained within this document. ASR products are not designed for use in life-support equipment or applications that would cause a life-threatening situation if any such products failed. Do not use ASR products in these types of equipment or applications.

Copyright © 2020. ASR International Ltd. All rights reserved..

Table of Contents

1	前言.....	4
1.1	UEFILTER 主要功能.....	4
2	使用用法.....	5
2.1	启动 UEFILTER.....	5
2.2	FILTERING DIAG MESSAGE.....	5
2.3	FILTERING GKI MESSAGE.....	6
3	APPENDIX.....	7
3.1	REPORT ISSUES.....	7
3.2	UPDATE THIS DOCUMENT.....	7
3.3	REVISION HISTORY.....	7

1 前言

1.1 UeFilter 主要功能


UeFilter向UE发送filter,通过它可以设置哪些UE Message (DIAG/GKI or DSP)能被UE上报到Catstudio.

2

使用用法

2.1 启动 UeFilter

1、在 CATStudio 窗口->Modules->UeFilter。



2.2 Filtering DIAG Message

Step1:在 UeFilter 窗口选择 DIAG Filter 标签。

Step2: 配置需要上报的消息，方法如下：

- 1) 勾选表示需要被打印显示的消息
- 2) 不勾选表示过滤不被打显示的消息。




Step3: 点击“Set Targe Device”按钮;

Step4: 点击“Send To Targe”按钮，向 UE 发送 filter;

2.3 Filtering GKI Message

Step1: 在 UEFilter 窗口选择 Gki Filter 标签。

Step2: 配置需要上报的消息，方法如下：



Step3: 点击“Set Targe Device”按钮;

Step4: 点击“Send To Targe”按钮，向 UE 发送 filter;

3 Appendix

3.1 Report issues

Please visit webs: <http://support.asrmicro.com>.

Or contact ASR FAE/AE

Or please send email to lianghuxu@asrmicro.com with "PC Tools User Doc Issue/Update: ..." title

Or submit an issue at CQ web: <http://sh2-cq01.asrmicro.com/cqweb/login>.

3.2 Update this document

Please send updated document to lianghuxu@asrmicro.com with "PC Tools User Doc Issue/Update: ..." title for merging, and you will receive merged latest version.

3.3 Revision History

Rev	Description	Date
1.00	Initial version	2012-04-11
1.01	Commit to SVN.	2012-04-19